



Step 1: Installation of the RAM Heatsink / ATI VRM Heatsink

* Refer to AMD HD 7970 as reference.



Before installing heat dissipation plate, clean the chip surface with ethanol to remove oil film or stain which may block heat transmission, so as to enhance adhesion of heat dissipation plate.




*Note:

RAM Heatsink A needs to be placed at this position. (If RAM heatsink B was placed at this position, it will hit MK-26's heatpipe.)

In accordance to the PCB layout, select the best RAM heatsinks for Your VGA RAM and VRM. Whenever Possible select the biggest heatsink (RAM heatsink B) for best cooling effect.


Step 2: Installation of VGA cooler



Spring-loaded Screw /

Black Nickel-plated Spring-loaded Screw

Reminder: Fan connector should be installed before the installation of the VGA heatsink.




Hold the VGA card and have the gold finger side face toward you with the VGA card facing downward. Insert the first spring loaded screw through the Omni-Mount Backplate and through the VGA card


starting from the upper right hand corner.

Use the same method for lower left hand corner. After this is done the other two remaining sets of holes will align automatically. Use the spring loaded screw to secure in place.

Compatibility List



Omni-Mount Bracket B



(1)**NVIDIA** Geforce GTX TITAN GTX 680 GTX 580 GTX 660 GTX 570 GTX 660 Ti GTX 670 (Exclude EVGA GTX 570 HD)
GTX 480 GTX 650 Ti 8800 Ultra(G80) 8800 GTX(G80) 8800 GTS(G80)

(3) AMD Redeon HD 7770 (Exclude XFX HD 7770) HD 7750

4 **NVIDIA** Geforce GTX 560 GTX 560 SE GTX 560 Ti (Exclude EVGA GTX 560 Ti FPB (Exclude EVGA GTX 560 Ti SC) GTX 550 Ti GTX 460 GTX 460 SE

	2
AMD Redeon	NVIDIA Geforce
HD 7970 HD 5850 HD 7950 HD 5830 HD 7870 HD 4890 HD 7850 HD 4870 HD 6970 HD 4850 HD 6950 HD 4830 HD 6870 HD 3870 HD 6850 HD 3850 HD 6790 HD 5870	GTS 450 9800GTX GTS 250 9800GT GTS 240(OEM) 9600GT GTS 150(OEM) 8800 GTS512(G92) 8800 GSO 512 7900 GTX 7900 GT 7900 GT 8800GT 7900 GS 8800GT 7800 GTX 8800GTS (G92) 7800 GTX

⚠ For a complete list of VGA cards please refer, to www.prolimatech.com.

↑ To listed Models are based on ATI and Nvidia's reference designs Manufacturers not following this reference layout will not work with MK-26.



Spring-loaded Screw and Black Nickel-plated Spring-loaded Screw Installation

PWM Fan Connector

Please use the Spring-loaded Screw to install ADM Radeon 7970/7950 VGA card.

Regarding to other VGA cards, please substitute the Black Nickel-plated Spring-loaded Screw for the Spring-loaded Screw. For other VGA cards



Black Nickel-plated Spring-loaded Screw For AMD 7970/7950



Spring-loaded Screw